

# Intelligent Infrared Carbon Dioxide Module (Model: MH-Z14A)

## User's Manual V1.4

Issue Date. Mar. 31<sup>st</sup>,2021

Zhengzhou Winsen Electronics Technology CO., LTD.

## Statement

The copyright of this manual belongs to Zhengzhou Winsen Electronics Technology Co., LTD. Without the written permission, any part of this manual shall not be copied, translated, stored in database or retrieval system, also can't spread through electronic, copying, record ways. Thanks for purchasing our product. In order to enable customers to better use the product and reduce the faults caused by misuse, please read the manual carefully and operate it correctly in accordance with the instructions. If users disobey the terms or remove, disassemble, change the components inside of the sensor, we shall not be responsible for the loss.

The specific such as color, appearance, sizes ...etc., please in kind prevail.

We are devoting ourselves to products development and technical innovation, so we reserve the right to improve the products without notice. Please confirm it is the valid version before using this manual. At the same time, users' comments on optimized using way are welcome.

Please keep the manual properly, in order to get help if you have questions during the usage in the future.

Zhengzhou Winsen Electronics Technology CO., LTD

## MH-Z14A NDIR CO2 Module

## 1. Profile

MH-Z14A NDIR Infrared gas module is a common type, small size sensor, using non-dispersive infrared (NDIR) principle to detect the existence of  $CO_2$  in the air, with good selectivity, non-oxygen dependent and long life. Built-in temperature sensor can do temperature compensation; and it has digital output and PWM output. This common type infrared gas sensor is developed by the tight integration of mature infrared absorbing gas detection technology, Precision optical circuit design and superior circuit design.



#### 3. Main Features

Chamber is gold plated, water-proof and anti-corrosion High sensitivity, low power consumption Good stability Temperature compensation, excellent linear output Multiple output modes: UART, PWM Long lifespan Anti-water vapor interference, anti-poisoning

#### 2. Applications


*HVAC refrigeration	*Air cleaner device	*Indoor air quality monitoring
*Smart home	*Ventilation system	


#### 4. Main technical parameters


Model No.	MH-Z14A			
Detection Gas	CO2 gas			
Working voltage	DC (5.0±0.1V)			
Average current	< 40 mA (@5V supply)			
Peak current	125mA (@5V supply)			
Interface level	3.3 V (5V compatible)			
Measuring range	400~10000ppm optional			
Outout sizes	Serial port(UART) (TTL)			
Output signal	PWM			
Preheat time	1min			
Response Time	T90 < 120s			
Working temperature	-10°C ~ 50°C			
Working humidity	0~95%RH(no condensation)			
Storage temperature	-20°C ~ 60°C			
Weight	14 g			
Lifespan	>10 years			

Target Gas	Measuring Range	Resolution	Accuracy
	400~2000ppm		
Carbon Dioxide (CO2)	400~5000ppm	1ppm	±(50ppm +5%reading value)
(02)	400~10000ppm		15/01 cauling value)


#### 5. Structure








## 6. Definition for pins



PIN No	Description
1,15,23	Power positive (Vin)
2,3,12, 22	Power negative (GND)
4,5,21	NC
6,26	PWM
8, 20	HD(for zero-point calibration, low level lasting for
	over 7 sec is effective)
7,9	NC
11, 14, 24	UART (RXD) TTL data input
10,13, 25	UART (TXD) TTL data output

7. Two Output ways

• PWM output



#### •Serial port output (UART)

#### Hardware connection

Connect module's Vin-GND-RXD-TXD to users' 5V-GND-TXD-RXD. (Users must use TTL level. If RS232 level, it must be converted.)

#### Software setting

Set serial port baud rate be 9600, data bit 8 bytes, stop bit 1byte, parity bit null.

#### **Command List:**

0x86	Gas concentration
0x87	Calibrate zero point (ZERO)
0x88	Calibrate span point (SPAN)
0x79	ON/OFF Self-calibration function for zero point
0x99	Detection range setting

#### **0x86-** Read CO2 concentration

Sending c	ommand									
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8		
Start Byte	Reserved	Command	-	-	-	-	-	Checksum		
0xFF	0x01	0x86	0x00	0x00	0x00	0x00	0x00	0x79		
Return va	lue									
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8		
Start Byte	Command	Concentration	Concentration	-	-	-	-	Checksum		
(High 8 Byte) (Low 8 Byte)										
0xFF	0x86	HIGH	LOW	-	-	-	-	Checksum		

#### CO2 concentration = HIGH \* 256 + LOW

For example:

#### Send command FF 01 86 00 00 00 00 00 79, Return value FF 86 02 20 00 00 00 00 58

How to calculate concentration: convert hexadecimal 02 into decimal 2, hexadecimal 20 into decimal 32, then 2\*256+32=544ppm

#### 0x79- On/Off Self-calibration for Zero Point

Send command-No return value

Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Reserved	Command	-	-	-	-	-	Checksum
0xFF	0x01	0x79	0xA0/0x00	0x00	0x00	0x00	0x00	Checksum

For example:

ON this function, send command: FF 01 79 A0 00 00 00 00 E6

OFF this function, send command: FF 01 79 00 00 00 00 00 86

NOTE: This function is on when Byte3 is 0xA0 while this function is off when Byte3 is 0x00.

Default status is "this function is on".

0x99- Det	0x99- Detection range setting									
Send comr	mand-No return	value								
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8		
Start	Reserved	Com	Reserved	Detection	Detection	Detection	Detection	Check		
Byte		mand		range 24~32	range 16~23	range 8~15	range 0~7	sum		
				bit	bit	bit	bit			
0xFF	0x01	0x99	0x00	Data 1	Data 2	Data 3	Data 4	Check		
								sum		
Note: Dete	ection range sh	ould be 0	~2000, 0~5000,	, or 0~10000ppr	n.					
For examp	For example: set 0~2000ppm detection range, send command: FF 01 99 00 00 00 07 D0 8F									
	set 0~10000	ppm det	ection range, se	nd command: FI	01 99 00 00 00 2	27 10 2F				

1. Checksu	m calculatio	n method						
Checksum	= (Negative (	(Byte1+Byte2+	Byte3+Byte4+	Byte5+Byte6+Byt	te7))+1			
For exampl	e:							
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Reserved	Comman	-	-	-	-	-	Check
		d						sum
0xFF	0x01	0x86	0x00	0x00	0x00	0x00	0x00	Check
								sum
Calculating	Checksum:							
1, Ac	dd Byte 1 to I	Byte 7: 0x01 +	0x86 + 0x00 +	-0x00 + 0x00 + 0	x00 + 0x00 = 0x87	7		
2. Ne	egative: 0xFF	-0x87 = 0x78	}					
3、Th	en+1: 0x78	+ 0x01 = 0x79	9					
С	language							
char getC	heckSum	(char *packe	et)					
{								
char	i, checksu	m;						
for( i	= 1; i < 8;	i++)						
{								
	checksum	+= packet[i]	•					
}								
chec	ksum = 0x	ff – checksu	m;					
chec	ksum += 1	,						
retur	n checksu	m;						
}								

#### **8.Zero Point Calibration**

#### About zero point calibration:

This module has three methods for zero point calibration: hand-operated method, sending command method and self-calibration. All the zero point is at 400ppm CO2.

**Hand-operated method**: Connect module's HD pin to low level(0V), lasting for 7 seconds at least. Before calibrating the zero point, please ensure that the sensor is stable for more than 20 minutes at 400ppm ambient environment.

#### Sending command method:

Zero and Span point calibration can be achieved by sending a calibration command to the sensor via the serial port (URAT). Zero and SPAN point calibration commands are as follows:

0x87-ZERO	POINT CALIBI	RATION						
Send comm	and-no returr	n value						
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Reserved	Command	-	-	-	-	-	Checksum
0xFF	0x01	0x87	0x00	0x00	0x00	0x00	0x00	0x78
For example	2:						·	
Put the mo	dule in 400pp	m standard C	O2 gas or clean outdo	or environment for a	at least 20 n	nin;		
Send comm	and FF 01 87	00 00 00 00 0	0 78 for zero point cal	ibration.				
Caution: Fo	rbid sending 1	this command	l in other environmen	t except above.				
0x88- SPAN	I POINT CALIB	RATION						
Send comm	and-no returi	n value						
Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
Start Byte	Reserved	Command	Span(High 8 Byte)	Span(low 8 Byte)	-	-	-	Checksum
<b>OxFF</b>	0x01	0x88	HIGH	LOW	0x00	0x00	0x00	Checksum
For example	e:			•	·		•	
Put the mo	dule in 2000p	pm CO2 gas,	stability for 20 min at	least.				
If span valu	ie is 2000ppm	, then HIGH=	2000/256, LOW = 200	D % 256				
Send comm	nand FF 01 88	07 D0 00 00 0	0 A0 for span calibrat	ion				
Caution: Ze	ro calibration	should be do	ne before span calibra	ation.				
It is recomm	mended to us	e 2000ppm as	the SPAN calibration	value.				
If lower val	ue as the spa	n value is nee	ded, choose a value a	bove 1000ppm.				

#### Self-calibration:

After the module works for some time, it can judge the zero point intelligently and do the zero calibration automatically. The calibration cycle is every 24 hours since the module is power on. The zero point is 400ppm. This method is suitable for office and home environment, not suitable for agriculture greenhouse, farm, refrigerator, etc.. If the module is used in latter environment, please turn off this function.

#### 9. Notes

9.1 Please avoid the pressure of its gilded plastic chamber from any direction, during welding, installation, and use.

9.2 When placed in small space, the space should be well ventilated, especially for diffusion window.

9.3 The module should be away from heat, and avoid direct sunlight or other heat radiation.

9.4 The module should be calibrated termly, the suggested period is not longer than 6 months.

9.5 Do not use the sensor in the high dusty environment for long time.

9.6 To ensure the normal work, the power supply must be among 4.5V~5.5V DC rang, the power current must be not less than 150mA. Out of this range, it will result in the failure of the sensor. (The concentration output is low, or the sensor can not work normally.)

9.7 During the zero point calibration procedure by manual, the sensor must work in stable gas environment (400ppm) for over 20 minutes. Connect the HD pin to low level (0V) for over 7 seconds.

#### Zhengzhou Winsen Electronics Technology Co., Ltd

Add: No.299, Jinsuo Road, National Hi-Tech Zone, Zhengzhou 450001 China
Tel: +86-371-67169097/67169670
Fax: +86-371-60932988
E-mail: sales@winsensor.com
Website: www.winsen-sensor.com